



BBC 52 E



No	Code	Name	Qty	No	Code	Name	Qty
14,1		Aluminum working shaft ϕ 26X1430B	1	23	028041	Fixed plate for the guard(26mm)	1
14	044633	Aluminum working shaft ϕ 26X1430B Assy	1	22	044677	P type front handle set	1
13		M5x25 Screw	1	22,1		M5x28 Screw	2
12		M5x12 Screw	3	21	044638	Throttle grip assembly C	1
11		M6x30 Screw	1	20	028041	Spool Assy DB	1
10	044634		1	19	017131	New 3T blade	1
9	044635		1	17	044639	Gear Case	1
8		M6x30 Screw	5	16	044640	Hardness axes ϕ 8x1480	1
7	044636	Connecter assy	1	15	044641	Big Quartet Hard Shaft Joint	1
6		M10_Nut	1	14,2		Oil-retaining bearing Assy	5
5		Spring washer 10	1				
4		Flat washer 10	1				
3		Holding plate rubber gasket	1				
2	046368	Fuel tank bracket assy	1				
1,1	046381		1				
1	046369		1				
31		ST4.2x16-H-F	2				
30	040243	Nylon line cutting blade	1				
29	044637	Protection guard bracket	1				
28		ST4.2x10-H-F	1				
27		Protection guard C lower platen	1				
26		ST4.8x20-H-F_Half Tooth Screw	1				
25		Protection guard C	1				
24		M6x25_Half Tooth Screw	2				

BBC 52 E explode view list

BBC 52 E



No	Code	Name	Qty	No	Code	Name	Qty
1	040197	Screw axes	2	25	044624	Starter assy	1
2		Wave washer	2	26		M5x25 screw	4
3	040198	Clutch	1	27	046388	Bearing,needle	1
4		Washer B	2	28	046389	Piston pin check ring	2
5		M5x20 screw	12	29	046390	Piston pin	1
6	046371	Fly wheel cover	1	30	044625	Piston	1
7		Round pin Φ 4x10	2	31	044626	Piston ring	2
8		M8 nut	2	32	040212	Cylinder gasket	1
9		Spring washer 8	1	33	044627	Cylinder	1
10		Flat washer 8	1	34	046375	Muffler gasket assy A	1
11	044620	Fly wheel	1	35	046376	Muffler assy	1
12	044662	Ignition coil	1	36	046391	Muffler steel cover	1
13		M5x35 screw	4	37		Flat washer 5X16X1	1
14	046372	Front-half crankshaft case	1	38		M5x12 screw	1
15	020855	Oil seal TC15x30x7	1	39		Big flat washer 6	2
16	010771	Bearing 6202/P6	2	40		M6x60 screw	2
17	044622	Crankshaft	1	41	010866	Spark plug	1
18	032478	Half-round key3*5*13	1	42		Screw	4
19	010563	Oil seal TC12x22x7	1	43		Windshield	1
20		Round pin B5x10	2	44	046392	Engine case cover	1
21	040205	Crankshaft gasket	1	45		M5x16 screw	2
22	046373	Back-half crankshaft case	1	46		Flat washer 5x12x2	1
23	044663	Starter catch plate assy	1	47	046378	Top cover	1
24	040227	Starter gasket	1	48	040218	Inlet gasket	1

BBC 52E Engine explode view list

