



BC 26 ES



No	Code	Name	Qty	No	Code	Name	Qty
1	044655	Connector assy	1	17	044658	Nylon cutter connector (Aluminum)	1
2		M5x12 screw	3	18	042157	Curved shaft safty guard assy	1
3		M5x25 screw	2	18,1		Curved shaft safty guard	1
4		Belt Connector assy	1	18,2		Nylon line knife	1
4,1	013483	Belt Connector fixed block	1	18,3		M5x45 screw	1
4,2	013485	Belt Connector	1	18,4		Flat washer 5.5x15x1	1
5		M5x20 screw	1	18,5		ST4.8x12-H-F	2
6		M5_Nut	1	18,6		Safty guard small plate	1
7	044703	Hardness axes $\phi 8 \times 762$	1	19	042149	Nylon spool B	1
8		M6x20 screw	4	20		M5x30 screw	1
9	044704	Small Quartet Hard Shaft Joint	1	21	044660	Soft shaft 630	1
10		A sponge jacket	1	22		Flexible shaft check ring	1
11	044702	Aluminum working shaft $\phi 26 \times 760N$ Assy	1				
11,1		Aluminum working shaft $\phi 26 \times 760N$	1				
11,2		Oil-retaining bearing	3				
12	044656	Throttle grip assembly C	1				
13		M5x8 screw	2				
14	046351	D type front handle set	1				
14,1		D type front handle	1				
14,2		D type front handle holding plate	1				
14,3		M6x40 square head bolts	1				
14,4		Plastic hand screw nut M6	1				
15		Steel shaft coupling assy	1				
16	044657	Curved Aluminum shaft $\phi 26 \times 630$	1				

BC 26 ES Engine explode view list (1)

BC 26 ES



No	Code	Name	Qty	No	Code	Name	Qty
1	044642	Screw axes	2	25		M4x16 screw	2
2		Wave washer	2	26		M4x16 screw	2
3	044643	Clutch	1	27	046335	Needle bearingKBK81111	1
4		Flat washer6.1x15x1.2	2	28	046336	Piston pin check ring	2
5		M5x20 screw	6	29	046337	Piston pin	1
6	046329	Fly wheel cover	1	30	044648	Piston	1
7		M8x1 nut	1	31	044649	Piston ring	2
8		Spring washer 8	1	32	046338	Cylinder gasket	1
9		Flat washer 8	1	33	044650	Cylinder	1
10	044644	Fly wheel	1	34		M5x25 Screw	6
11		M5x30 screw	4	35	010866	Spark plug	1
12		Round pin B4x10	4	36	046339	Muffler gasket assy	1
13	046330	Front-half crankshaft case	1	37	046340	Muffler B	1
14	044645	Ignition coil	1	38	046343	Muffler steel cover	1
15	010563	Oil seal TC12x22x7	2	39		Flat washer 5	4
16	025367	Bearing 6001	2	40		M5x60 screw	2
17	044646	Crankshaft	1	41		ST3X9-H-C	4
18		Half-round key3*3.7*13	1	42		Windshield	1
19	046331	Crankshaft gasket	1	43	046344	Engine case cover	1
20	046330	Back-half crankshaft case	1	44		Flat washer 5x12x2	1
21	046333	Starter catch plate assy	1	45		M5x12 Screw	1
22	044647	starter assy	1	46	046345	Top cover	1
23		Holding plate rubber gasket	1	47	046346	Inlet gasket	1
24	046334	Fuel tank holding plate	1	48	044651	Inlet pipe	1

BC 26 ES Engine explode view list (2)

