



BC 43 EB



No	Code	Name	Qty	No	Code	Name	Qty
1	044673	Connector assy A	1	10,2		M5x30 Screw	1
2		M6x30 Screw	6	11	044709	Handle left part	1
3		M5x12 Screw	2	12		Fixed plate for the guard(28mm)	1
4	044674	Aluminum working shaft ϕ 28x1495C Assy	1	13		M6x25_ Half Tooth Screw	2
4,1		Aluminum working shaft ϕ 28x1495C	1	14	042158	Protection guard C1	1
4,2		Oil-retaining bearing	6	14,1		Protection guard C	1
5	044686	Hardness axes ϕ 8x1520	1	14,2		Protection guard C lower platen	1
6		Belt Connector assy	1	14,3		ST4.2x10-H-F	1
6,1		Belt Connector fixed block	1	14,4		Protection guard bracket	1
6,2		Belt Connector	1	14,5	046326	Nylon line cutting blade	1
7		M5_ Nut	1	14,6		ST4.2x16-H-F	2
8		M5x20 Screw	1	14,7		ST4.8x20-H-F_ Half Tooth Screw	1
9	044653	Adjustable handle fixed base	1	15	044664	Gear Case 28	1
9,1		M8x60 triangular knob	1	16		ϕ 28 pipe clamp	2
9,2		ϕ 26 Rotating seat	1	17		ϕ 19 pipe clamp	1
9,3		ϕ 26 holding plate	1	18	017131	New 3T blade	1
9,4		ϕ 19Rotating seat	1	19	028041	Spool Assy	1
9,5		ϕ 19 holding plate	1				
9,6		Spring	1				
9,7		Flat washer 8	1				
9,8		M6x16 Screw	2				
9,9		Rubber sleeve	1				
10	044670	Handle right part	1				
10,1		M5_ lock nut	1				

BC 43 EB Shaft explode view list

BC 43 EB



No	Code	Name	Qty	No	Code	Name	Qty
1	040197	Screw axes	2	25	044624	Starter assy	1
2		Wave washer	2	26		M5x25 screw	4
3	040198	Clutch	1	27		Bearing,needle	1
4		Washer B	2	28	040210	Piston pin check ring	2
5		M5x20 screw	12	29	046374	Piston pin	1
6	046371	Fly wheel cover	1	30	044665	Piston	1
7		Round pin $\Phi 4 \times 10$	2	31	044666	Piston ring	2
8		M8 nut	2	32	040212	Cylinder gasket	1
9		Spring washer 8	1	33	044667	Cylinder	1
10		Flat washer 8	1	34	046375	Muffler gasket assy A	1
11	044620	Fly wheel	1	35	046376	Muffler assy	1
12	044662	Ignition coil	1	36	046391	Muffler steel cover	1
13		M5x35 screw	4	37		M5x12 screw	1
14	046372	Front-half crankshaft case	1	38		Flat washer 6	2
15	020855	Oil seal TC15x30x7	1	39		M6x60 screw	2
16	010771	Bearing 6202/P6	2	40	010866	Spark plug	1
17	040204	Crankshaft	1	41		ST3x9-H-C Screw	4
18	032478	Half-round key3*5*13	1	42		Windshield	1
19	010563	Oil seal TC12x22x7	1	43	046377	Engine case cover	1
20		Round pin B5x10	2	44		M5x16 screw	2
21	040205	Crankshaft gasket	1	45		Flat washer 5.5x15x1	1
22	046373	Back-half crankshaft case	1	46	046378	Top cover	1
23	044663	Starter catch plate assy	1	47	040218	Inlet gasket	1
24	040227	Starter gasket	1	48	044668	Inlet pipe	1

BC 43 EB Engine explode view list

