


ET 1000 (2016-...)





EXPLODED PARTS LIST

Year: 2017

Page(s): 2/2

ET 1000 (2016 - ...)

No	Code	Name	Qty	No	Code	Name	Qty
1	048014	Split washer	1	35	048006	Power line	1
2	047996	Fan blade	1	36	048007	Connector	1
3	048015	Spindle cover	1	37	048008	Cable clamp	1
4		Stator screw	2	38		Self tapping screw	4
5		Spring washer	2	39		Cable sleeve	1
6		Washer	2	40	048009	Rubber washer	4
7	048016	Rear support	1	41	048032	Left housing	1
8	048017	608 Bearing	1	42	048010	Left overlay cover	1
9	048030	Stator assy'	1	43	048011	Push button	1
10		Self tapping screw	10	44	048012	Limit sleeve	1
11	048032	Right housing	1	45	048013	Pressure spring	1
12	047997	Right overlay cover	1	46		Self tapping screw	2
13	048029	Rotor assy'	1	47		Upper handle	1
14	048018	6900 bearing	1	48		Hexagon nut	1
15		Rubber column	1	49		Knob	1
16	048019	Front support	1	50		Lower handle	1
17	047998	Carbon brush	2	51		Self tapping screw	5
18	047999	Copper brush holder	2	52		Outer hex screw	1
19	048000	Brush support	2	53	048027	Rear connector tube assy'	1
20		Machine screw	7	54	048028	Front connector assy'	1
21	048020	Multi-roll bearing	1	55	048031	Shield	1
22	048021	Gear shaft	1	56		Nut	1
23	048022	Bearing 628Z	1	57		Blade	1
24	048015	Spindle cover	1	58		Guide bar sleeve	1
25	048023	Clamp	1	59		Inner-hexagon screw	1
26	048024	The elastic cylindrical pin	1	60		Cutting head base	1
27	048025	Connector shaft	1	61		Rivet	2
28	048001	Inductance wire	1	62	048026	Pressure spring	1
29		Blown-sponge	1	63		Nylon wire	5M
30	048002	PCB board	1	64		Cutting head sleeve assy'	1
31	048003	Switch trigger	1	65		Knob	1
32	048026	Pressure spring	1	66		Screw	1
33	048004	Switch	1	67		Flat gasket	1
34	048005	Capacitance	1	68		Braces	1
35				69		Inner hex spanner	1
36							
37							
38							
39							
40							
41							
42							
43							
44							
45							
46							
47							
48							