



EXPLODED PARTS LIST

VET 1835 PRIME

No	Code	Name	Qty	No	Code	Name	Qty
1		SCREW	3	48	60572	BRAKE SPRING	1
2		PRESSING PLATE	1	49		FLAT GASKET	1
3	60546	MICRO-SWITCH	2	50	60573	OIL TANK COVER	1
4		COPPER PIPE	1	51		OIL TANK RING	1
5	60547	CABLE COVER	1	52		HOOK	1
6	60548	CABLE	1	53	60574	OIL TANK	1
7		CONNCTION LINE	1	54	58375	OIL TANK CONNECTION PLUG	1
8	60549	SWITH	1	55		SPONEGO	1
9		BUTTON SPRING	1	56	60575	OIL TANK CONNECT HEAD	1
10		SWITCH LOCK BUTTON	1	57		OIL TANK RING	1
11		SCREW	1	58		OIL INLET PIPE	1
12		PUSH POLE	1	59		SCREW	2
13		PUSH POLE SPRING	1	60	60576	OIL PUMP ASSEMBLY	1
14		SCREW	2	61		OUTPUT OIL PIPE	1
15		BRAKE SPRING	1	62	60577	OUTPUT OIL MOUTH	1
16	60550	NUT	3	63	51174	O SHAPE SEAL	1
17	60551	SMALL GEAR	1	64		OIL INLET PIPE	1
18		GEAR SHAFT SLEEVE	1	65		OIL DISPLAY CONTROL PANEL	1
19	60552	LEFT HANDLE	1	66		LAMP SHADE	1
20	58363	BEARING	1	67		SPONGE BAR	1
21	60553	ROTOR	1	68		GEAR BOX COVER	1
22	58360	BEARING	2		60579	INSERT STUD	2
23	60554	WIND SCREEN	1	69	60580	RIGHT HANDLE	1
24	60555	STATOR	1	70	60581	SPROCKET	1
25	58361	THREE COMBINATION SCREW	2	71	58394	E SHAPE GASKET	1
26		SCREW	24	72	60582	GROMMET TYPE SEALS	1
27	60556	BRUSH HOLDER COVER	2	73	60583	THERMAL BAFFLE	1
28	60557	CARBON BRUSH	2	74		SCREW	2
29	60558	BRUSH HOLDER	2	75		GUIDE BAR	1
30	60559	HANDLE BOARD	1	76		CHAIN	1
31	60561	REAR COWL	1	77		BAR COVER	1
32		SCREW	1	78	60584	ADJUST THE STUD	1
33	60562	SAFETY GUARD	1	79	60585	ADJUST PIN	1
34	60563	NUT	1	80	60585	END COVER SEAL RING	1
35	60564	BIG GEAR	1	81	60588	CHAIN COVER	1
36		NEEDLE BEARING	1	82		LINING	2
37		FLAT GASKET	2				
38	60565	BRAKE SPRING	1				
39	60566	OUTPUT SHAFT	1				
40	60567	WORM	1				
41	58363	BEARING	1				
42	60568	DUST COVER	1				
43		SCREW	6				
44		SCREW	2				
45	60569	FIX BOARD	1				
46	60570	CONNECTION BAR	1				
47	60571	BRAKE BAR	1				

VET 1835 PRIME